



PP170

Before initiating the installation:

Read all instructions.
Silicone must be used

Avant de commencer l'installation :

Lire toute les instructions.
Vous devez obligatoirement utiliser du silicone.

Antes de iniciar la instalación:

Lea todas las instrucciones.
Debe utilizar silicona

**Tools and equipment requested / Outils et matériels requis /
Herramientas y material requerido de instalación :**



Silicone



TEFLON



riobelpro.ca



